

Instructions for fitting the Rain Hood to Little Cracker Cowl.



Remove upper cone from Top Cowl assembly by drilling three rivets off, using 1/8 or 3.2mm drill- (mark position of cone relative to cowl assy.)

Note: Rain hood can be fitted without removal of top cone if cowl is not fitted to the flue



Remove split pin from Rain Hood shaft



Bend the three tabs using pliers so that it fits the tapered cone as best as possible.

Normally curve the tabs and test fit.



Clamp into place using vice grips or similar – make sure tube is aligned straight with centre line as possible.



Drill through cone using 4.0mm drill and aim to get middle of tab – insert rivet and pull up, do same for other two tabs making sure tube is as straight as possible

Re insert hood into tube and refit split pin, bend or spread legs of split pin.

Refit cone – fitting stainless screws will make it easier to remove for flue cleaning.